

Pivot Drain Installation Instructions

Please provide these instructions to contractor at point of sale.

This device is provided with "Straight Threads" and will not produce a better seal by continued tightening as with "Tapered Threads". A good, water tight seal is achieved by use of generous quantities of "High Quality TEFLON PASTE" such as "La-Co Slic-Tite" brand.

The use of Teflon Tape or Plumber's Putty is NOT recommended on any part of this installation.

Hardware Supplied

- A. Rubber Grommet
- B. Overflow or Overflow Collar
- C. Flange
- D. Wedge Washer
- E. Decorative Nut
- F. Tail Piece

Instructions for use with Vitraform Standard Basins and Countersinks using Overflow or Overflow Collar:

1. Prior to final installation it is necessary to perform a "dry installation" WITHOUT Teflon Paste to establish the final length of **Tail Piece F**.
2. Install **Rubber Grommet A** by fitting it into and around the drain hole with the thin lip inside the bowl and the remainder below the basin. The bottom of the Rubber Grommet will fit into the top of the **Overflow or Overflow Collar B**.
3. Insert **Flange C** into drain hole of sink while holding **Overflow or Collar B** in place over bottom of **Grommet A** below sink.
4. Thread **Decorative Nut E** all the way onto **Tail Piece F** with counter bored side down.
5. Slide **Wedge Washer D** onto threaded portion of **Tail Piece F** with the flat, non-tapered side of Wedge Washer in contact with **Decorative Nut E**.
6. Thread **Tail Piece F** with **Decorative Nut E** and **Wedge Washer D** into **Flange C** and tighten **Decorative Nut E** so that **Wedge Washer D** seals against the bottom of the **Overflow or Overflow Collar B** while aligning the assembly to a firm, straight position.
7. Mark length of **Tail Piece F** relative to P-trap or European Siphon and appropriate waste location.
8. Disassemble the Pivot Drain Assembly and cut **Tail Piece F** at mark.
9. Reassemble as above but now use generous quantities of TEFLON PASTE on male threads of **Tail Piece F** AFTER threading on **Decorative Nut E** but BEFORE installing **Wedge Washer D**.
10. Install P-trap or European Siphon.
11. Clean excess TEFLON PASTE from assembled drain.
12. If a leak occurs it usually will be due to insufficient TEFLON PASTE under **Decorative Nut E**; reassemble appropriately. DO NOT OVERTIGHTEN, this will only result in damage to the Basin.

Instructions for use with Vitraform Freestanding Basins:

1. Vitraform Freestanding Basins do not require an overflow or collar. Follow instructions above, **but disregard the directions for the use of the Rubber Grommet and Collar**. See installation instructions for Freestanding basins.

