

Dome Drain Pop-up Set Installation Instructions

Please provide these instructions to contractor at point of sale.

A good, water tight seal is achieved by hand tightening.

The use of Teflon Tape or Plumber's Putty is NOT recommended on any part of this installation.

Hardware Supplied

- A. Rubber Grommet
- B. Overflow or Overflow Collar
- C. Drain Flange
- D. Drain Body
- E. Rubber Gasket
- F. Flat Rubber Washer
- G. Tail Piece Nut
- H. Tail Piece

Instructions for use with Vitraform Standard Basins and Countersinks using Overflow or Overflow Collar:

1. Install **Rubber Grommet A** by fitting it into and around the drain hole with the thin lip inside the bowl and the remainder below the basin. The bottom of the **Rubber Grommet** will fit into the top of the **Overflow or Overflow Collar B**.
2. Insert **Drain Flange C** into drain hole of sink while holding **Overflow or Collar B** in place over bottom of **Grommet A** below sink.
3. Screw on **Drain Body D** and align with properly seated **Rubber Gasket E** onto Drain Flange.
4. **HAND TIGHTEN** so that the assembly is held firmly making sure drain, grommet and overflow or collar are centered.
5. Cut **Tail Piece H** to appropriate length and attach to Drain Body using **Flat Rubber Washer F** and **Tail Piece Nut G**.
6. Install **P-trap or European Siphon**.

Instructions for use with Vitraform Freestanding Basins:

1. Vitraform Freestanding Basins do not require an overflow or collar. Follow instructions above, **but disregard the directions for the use of the Rubber Grommet and Collar**. See installation instructions for Freestanding basins.

