

Mono Mount Installation Instructions

Please provide these instructions to contractor at point of sale.

This product is for use with Vitraform Freestanding Basins only.

To install this product the wall must be opened to the studs from at least one side. The strength and integrity of this installation is dependent upon the structure of the wall so care must be taken that the stud on which the mount will attach is strong enough to support the total assembly.

Planning is an important part of this installation because all wall structure and finish must be complete before the Monomount trim and basin can be installed. The waste, supply lines, and wall mounted faucet must be installed at their correct locations. No adjustments can be made to these components after the wall is closed up.

1. Stud Preparation: The Monomount is attached to the left or right side of a wooden or metal stud. Determine the location of the installation and complete all in-wall plumbing necessary for the installation. Make sure stud is correctly located relative to the center of the Rough. If not, block the stud to its correct location. The rough mount is offset to allow for faucet and drain centering.

2. Attachment of Rough: In most 2X4 stud wall installations the Rough should be placed as far away from the wall surface as possible; there is more adjustment out than there is in. Waterproof wall finish (tile, mirror, stone) is recommended in a wet location. Check position of Steel Rough on stud to accommodate total thickness of finished wall. Attach using appropriate hardware; if possible use 5/16" (8mm) machine bolts, nuts and washers. If blocking prevents the use of machine bolts, 5/16" (8mm) or 3/8" (10mm) Lag Screws can be substituted with wooden stud walls.

3. Trim Installation: Slide Trim Rosette and Trim Support Arm onto 1" (25mm) Rough rod with the #10-24 set screw facing down. Tighten the set screw so the arm correctly orients so the basin will be level. Once the basin is attached to the arm it can be leveled by loosening the set screw, making a level adjustment, and retightening the set screw.

4. Drain/Freestanding Basin Installation: Install drain/Freestanding Basin according instructions included with those products.

