

Rectangular Console Leg Installation Instructions (with or without Towel Bar)

Please provide these instructions to contractor at point of sale.

This support is designed to be used with Vitraform glass Counters and Countersinks. It may be ordered for counter height up to 36" (120 to 915mm), adjustable to +/- 1/4" (6mm).

The Rectangular Console Leg supports Vitraform Counters at the front in combination with Vitraform U- Channel (see pg B.2.12), Vitraform Flush Clips (see pg. B.2.8) or Vitraform Surface Clips (see pg. B.2.7) to support the back. Optional Towel Bar hardware is offered to be used with this installation. Drawings for approval are provided by the factory to coordinate glass and hardware components for planning and installation.

The Rectangular Console Leg is pre-assembled at the factory to simplify alignment at installation. If optional Towel Bar(s) are ordered, a wood "placeholder" is included in the assembly to indicate the relationship of Legs to Towel Bars.

INSTALL Counter to the back wall according to the instructions for the Vitraform support fitting selected. Temporarily support the front, outer edges of the Counter using a piece or pieces of wood cut to the appropriate length.

Installation of Console leg:

1. Assemble the **Plastic Bushing** and **Plastic Washer** on the **Decorative Cap Screw** and insert into 1/2" hole in Counter provided for leg. Place the second **Plastic Washer** over the end of the **Decorative Cap Screw** against the bottom of the Counter.
2. Thread **Upper Clip** of **Rectangular Console Leg** assembly onto **Decorative Cap Screw** and **HAND TIGHTEN** to underside of glass Counter. Make sure **Rectangular Leg** and **Set Screw** of **End Clip** are in the proper orientation so **Set Screws** are not visible from the front of the installation.
3. Adjust **Leveling Screw** at the bottom of **Console Leg** to its approximate correct length, and check leg with bubble level to make sure it is in plumb on two axis. Accurately mark the point on the floor where the **Leveling Screw** is sitting to locate a hole to be drilled to secure **Leveling Screw**.
4. Adjust the **Leveling Screw** back up and remove **Rectangular Console Leg**. Drill a 1/4" dia. x 1/4" deep (6 x 6mm) hole in floor as marked for the **Leveling Screw** to be inserted.
5. Permanently install Console leg as before. Remove temporary support and using a bubble level, adjust the Counter by turning the **Leveling Screw** while hand supporting the edge of the Counter to avoid over stressing the counter.

Optional Side Towel Bars

1. If **Side Towel Bars** are to be installed, after Legs are installed above, proceed to the next step.
2. Using Vitraform provided drawing for placement of side towel bars as a guide, drill holes in back wall which will accept fasteners appropriate to wall construction (anchors, screws, etc.).
3. Attach **Towel Bar End Clips** to wall on holes drilled above. These parts may be shipped assembled and set screwed to Side Towel Bars and will need to be removed for installation by loosening set screws.
4. Attach **Front Towel Bar** as indicated in exploded drawing, with or without **Side Towel Bar End Clips**.

If Side Towel Bars are included, slide them into Side Towel Bar End Clips and tighten set screws to secure them.

